


Three bit counter



`next(value) := value xor carry_in`

`carry_out := value & carry_in`

bit2.value	bit1.value	bit0.value
0	0	0
0	0	1
0	1	0

bit2.carry_out	bit1.carry_out	bit0.carry_out
0	0	0
0	0	0
0	0	1

